


Bell Set No.5 (Mark 236).



Note:-


A direct current through Bell Coils with - on terminal 6 should pull armature against bias spring when latter is fitted.

N505

4/4

Transposed
from Label

BELL SET N°5. (Mark 234).



N505

3/4

Transposed
from Label