



# TELEPHONE N<sup>o</sup> 3.

## (MARK 238)



N103. 29.5.17


T.L.439B.



\* GENERATOR ONLY FITTED WHEN REQUIRED FOR MAGNETO WORKING. (SEE DCM. N.111 FOR MAGNETO SET.)

CIRCULATION

GENERAL



FOR C.B.S. No. 1 SYSTEM CONNECT TERMINAL G TO EARTH & JOIN BELL COILS IN PARALLEL. (REMOVE STRAP BETWEEN INNERS & STRAP INNER TO OUTER TERMINALS). WHEN AN EXTENSION BELL IS REQUIRED CONNECT BETWEEN TERMINAL EB & G. IN PLACE OF STRAP.

FOR C.B.S. Nos. 2 & 3 SYSTEMS CONNECT CONDENSER M.C. No. 22 BETWEEN TERMINALS 2 & 3 (BELL COILS TO BE CONNECTED IN SERIES AS SHOWN) WHEN AN EXTENSION BELL IS REQUIRED CONNECT IN PLACE OF STRAP BETWEEN TERMINALS EB & G.

\* GENERATOR ONLY FITTED WHEN REQUIRED FOR PLAN No. WORKING (SEE DIAGRAM N 111 FOR MAGNETO SET)

# TELEPHONE No. 3 (MARK 238)


## WIRING DIAGRAM

1800


N 103

29 · 5 · 17

SUPERSEDED FOR NEW WORK  
BY N 251



### EXPLANATORY



Super-session Note added  
Redrawn & Draw Number T L 439 Deleted  
23.8.38  
Amendment

