


PLAN 1A

EXTENSION 2

BELL
CUT-OFF
SWITCH

EXTENSION 1



MAIN TELEPHONE

INCOMING CALLS
ALWAYS RING
THE BELL IN
THIS TELEPHONE

EXCHANGE LINE

* Plan 1A consists of a main station and an internal or external extension connected in parallel. Up to three such extensions may be provided on one installation. Each extension telephone (not the main) has a press button which may be used to switch the bell on or off as and when required.

Incoming calls may be answered at any telephone.

Each telephone can call the exchange direct.

Intercommunication between main and extensions is not provided.

Where the number of telephones required exceeds the permitted number of bells the bells in some extension telephones may be rendered permanently inoperative to avoid the need to provide a free ringing converter.

TMkD/TMk1.6.3

E N D