

SIEMENS

Operating Instructions

Hicom 150 E

DTMF Telephones

Pulse Telephones



These operating instructions describe only operations that are specific to your Hicom[®] 150 E Office (Release 2.0 and 2.2).

All functions and operating procedures are described. The operations you can use depend on the individual class of service of your telephone and on the configuration of your system.

When performing the various operations, you should note carefully which telephone you have, which mode it is set to, or both (see manufacturer's specifications and instructions).

For the basic operating functions of your telephone please refer to the relevant operating instructions.

Contents

Hicom 150 E Office	5
Symbols	5
Answering Calls	6
Making Calls	6
Reserve Trunk	6
Consultation Hold	7
Call Transfer	7

Accessing Other Functions Via Codes	9
Accepting a Waiting Call	9
Account Code	24
Activate Door Opener function	31
Actuating Relays	28
Appointment Reminder	30
Assign Station Number (Not for U.S.)	26
Associated Dialing	14
Associated Service	13
Automatic call distribution (UCD)	11
Call Forwarding	33
Call Pickup - Directed	32
Call Pickup - Group	32
Call Ringing Group	26
Call Waiting	9
Callback, Automatic	25
Caller ID Suppression (for outbound external call; only if requested from carrier)	25
Central COS Change	35
Conference, Five-Party	18
Do Not Disturb	10
DTMF Dialing (Tone Dialing; Only for Pulse Phones)	20
Hunt Group/Group Call	27
Log On CMI Unit/Ready to Log On (Not for U.S.)	21
MSN Trunk Forwarding (Only in a Multi-Device Connection with Release 2.2 or Later, Not for the U.S.)	34
Night Answer	22
Open Door	31
Override	14
Park Call	23
Preventing/Allowing Call Waiting	10
Radio Paging (Not for U.S.)	24
Release Trunk	20
Reset All Services	15
Retrieve Line	35
Retrieving Message	16
Room Monitoring (Baby Phone)	15
Sending a Message Text	17
Silent Monitor (U.S. Only)	21
Speaker Call	16
Speed Dial - Station (DTMF Telephones Only)	19
Speed Dial - System	19
Station COS Changeover (Locking/Unlocking Telephone)	29
Telephone Data Service	30
Toggle (between two parties)	20
Trace Call (only if requested from carrier, not for U.S.)	16
Trunk Flash, Recall to Network	28
Meaning of Functions	37
Overview of Codes	41
Speed Dial Destinations	Back Cover

Hicom 150 E Office

You can use your telephone to access the functions of the Hicom 150 E Office communication system via codes.

Symbols

Symbol	Meaning
--------	---------



Lift the handset (off-hook).



Speak.



Replace the handset (on-hook).



Press the specified keys.



Press the consultation hold key, signal key, flash key (not applicable to pulse telephones).



Dial the station number or code.



You hear a tone.

A long tone (positive confirmation tone) confirms that you have successfully activated a function or procedure.

A short tone (negative confirmation tone) indicates that the function or procedure was rejected.



Reference to a page where more information can be found.

Dial pulsing telephones



= Code **75**



= Code **76**

Answering Calls

Your telephone rings



Lift the handset.



Speak.

Making Calls



Lift the handset.



Internal: Dial the station number.

External: Dial the external code and external number.

Reserve Trunk



Lift the handset.

Dial the external code and external number.

If configured, you can wait five seconds, until the busy signal stops, when an external line is busy and thus **reserve** this **line** for yourself. Then replace the handset.



Once the line is free, your telephone will ring. When you lift the handset, you hear the external dial tone. Now dial the external number.

Consultation Hold

Initiating consultation hold (you are conducting a call)



Press the key.



Dial the number of the other party (internal/external dialing → 6).



Conduct a consultation call (the first call is on hold).

Ending consultation hold



Press the key.



Enter the code *0 or wait 2 seconds.

or (depending on the configuration)



Press the key twice.

Call Transfer

You are engaged in a call and would like to transfer it to another party



Press the key.



Dial the telephone number of the other party (internal/external dialing → 6).



Replace the handset either before the other party answers or after the other party answers.

8

You are engaged in a call and would like to announce and transfer it to a group of users with a speaker call (Release 2.2 and later)



Press the key.



Enter the code * 8 0.



Dial the group's station number and announce the call..



After a member of the group answers: replace the handset to transfer the call.

Accessing Other Functions Via Codes

Call Waiting



Lift the handset.



Dial the internal station number.
If the party is busy, wait approximately five seconds. The party is then called.

Accepting a Waiting Call

You hear a bleep tone during a call



Replace the handset (the current call is disconnected). Your telephone rings.



Lift the handset.

or



Press the key.



Enter the code *55, and conduct a call with the waiting party (the first call is on hold).

To return to the first call



Press the key.



Enter the code *0 or wait 2 seconds and resume the first call (the second call is disconnected).

or (depending on the configuration)



Press the key twice
and resume the first call (the second call is disconnected).

Preventing/Allowing Call Waiting

Preventing call waiting



Lift the handset.



Enter the code #490.

Allowing call waiting



Lift the handset.



Enter the code *490.

Do Not Disturb

Activating



Lift the handset.

If do not disturb is already activated, you hear a special dial tone.



Enter the code *97.

Deactivating



Lift the handset.



Enter the code #97.

Automatic call distribution (UCD)

Logging on at start of duty period



Lift the handset.



Enter the code *401.



Enter your personal group ID.

Logging off at end of duty period



Lift the handset.



Enter the code #401.

Logging off temporarily (unavailable)



Lift the handset.



Enter the code #402.

Logging back on after temporary logoff (available)



Lift the handset.



Enter the code *402.

Requesting work time (wrap-up time)

You have (or had) a UCD connection, before you replace the handset:



Enter the code *403.

Logging back on after work time

Lift the handset.



Enter the code #403.

Activating UCD night answer

Lift the handset.



Enter the code *404.



Enter the destination number.

Deactivating UCD night answer

Lift the handset.



Enter the code #404.

Associated Service

Activating and deactivating functions for other telephones.

- Do not disturb *97/#97
- Call forwarding *11, *12, *13/#1
- Advisory messages *69/#69
- Reset all services #0
- Send messages *68/#68
- Night answer *44/#44
- Caller ID suppression *86/#86
- Call ringing group *81/#81
- Hunt group/group call *85/#85
- Relay on/off *90/#90
- Changeover on/off (locking/unlocking telephone) *66/#66
- Activate door opener function *89/#89



Lift the handset.



Enter the code *83.



Enter the internal station number and the code (such as *97 to activate do not disturb or #97 to deactivate do not disturb) or enter the procedure.

Associated Dialing

Dialing aid for another telephone



Lift the handset.



Enter the code *67.



Enter the internal station number of the party you want to reach.



Enter the number of the destination station (external with external code, such as 0 or 9).

Override

Internal party called is busy



Press the key.



Enter the code *62.

Room Monitoring (Baby Phone)

Activating the telephone to be monitored



Lift the handset.
Place the handset next to the telephone.



Enter the code *88.

Deactivating the telephone to be monitored



Replace the handset.

Activating the feature (room monitoring)



Lift the handset of the telephone from which you are monitoring.



Enter the internal station number of the telephone in the room that is to be monitored.

Reset All Services

Canceling of user-activated functions

- Call forwarding
- Call ringing group
- Caller ID suppression
- Do not disturb
- Hunt group
- Messages received
- Callback requests (Release 2.2 and later)



Lift the handset.



Enter the code #0.

Speaker Call



Lift the handset.



Enter the code *80.



Dial the internal station number.

Trace Call (only if requested from carrier, not for U.S.)

You are conducting an external call



Press the key.



Enter the code *84.

Retrieving Message

A message has been recorded for you



Lift the handset.

You hear a special dial tone or an announcement.



Enter the code #683.

You are connected to the party who sent the message text or to the voice mail system.

Sending a Message Text

Sending



Lift the handset.



Enter the code *68.



Dial the internal station number.



Select a text number (0 - 9)

0 = Please callback

1 = Someone is waiting

2 = Appointment

3 = Urgent call

4 = Do not disturb

5 = Fax waiting

6 = Dictation please

7 = Please come see me

8 = Please make copies

9 = Ready to depart



Replace the handset.

Deleting messages that have been sent



Lift the handset.



Enter the code #681.



Replace the handset.

Conference, Five-Party

Initiating a conference (you are conducting a consultation call, first call is on hold → 7)

 Press the key.

   Enter the code *3.

Extending the conference; you are conducting another consultation call (→ 7)

 Press the key.

   Enter the code *3.

Leaving the conference

 Replace the handset.

Ending the conference (all parties)

 Press the key.

  Enter the code #3.

Remove ISDN central office party from the conference (only for U.S.)

 Press the key.

    Enter the code * 4 9 1.

Speed Dial - Station (DTMF Telephones Only)

Storing



Lift the handset.

*** 9 2**

Enter the code *92.

*** 0** to *** 9**

Select a memory location (*0 - *9).
You can write down the assignment in the table at the end of these operating instructions.



Dial the external code and external number
(wait five seconds).

Calling (dialing)



Lift the handset.

*** 7**

Enter the code *7.

*** 0** to *** 9**

Enter the memory location (*0 - *9).

Speed Dial - System

Dialing



Lift the handset.

*** 7**

Enter the code *7.

0 0 0 to **9 9 9**

Enter a system speed dial number:
000 - 299 or 000 - 999
(consult System Support).

Release Trunk



Lift the handset.



Enter the code *43.



Enter the trunk number you want released.

Toggle (between two parties)

**You are conducting a consultation call
(a call is on hold)**



Press the key again.



Enter the code *2.

You will be connected with the held party.

and so on

DTMF Dialing (Tone Dialing; Only for Pulse Phones)



You have established a connection.



Enter the code 7553.



Enter digits (they are transmitted as DTMF signals).

Silent Monitor (U.S. Only)



Lift the handset.



Enter the code *944.



Dial the internal station number.

Log On CMI Unit/Ready to Log On (Not for U.S.)



Lift the handset.



Enter the code *942.



Enter the code (ask your system administrator for the code).

Night Answer

Activating



Lift the handset.



Enter the code *44.



Enter the destination station within five seconds (internal station number).
If you enter * or make no entry, the default night answer is used.

Deactivating



Lift the handset.



Enter the code #44.

Park Call

Parking a call (you are conducting a call)

 Press the key.

   Enter the code * 5 6.

 to  Enter and make a note of the parking position (0 - 9). If the park position you have entered is already in use, a negative confirmation tone sounds. Please enter another park position.

 Replace the handset.

Retrieving a parked call

 Lift the handset.

   Enter the code #56.

 to  Enter the noted parking position number (0 - 9).

Radio Paging (Not for U.S.)

Paging another person



Lift the handset.



Enter the code *45.



Enter the internal station number of the paged party.

The paged party answers as follows:



Lift the handset.



Enter the code #45.



Enter the internal station number of your own telephone; a connection is set up to the paging party.

Account Code

Only in relation to call detail recording



Lift the handset.



Enter the code *60.



Enter the account code (up to eleven digits) and # (Depending on the configuration, you may or may not have to enter # to conclude input of the account code. Please consult System Support.)



Dial the external code (such as 0 or 9) and the external station number.

Callback, Automatic

Initiating callback (maximum of two; five in Release 2.2 and later):

Party is busy or is not answering:

 Press the key.

   Enter the code *58.

The system or user calls you back automatically as soon as this party is available or has used his/her telephone again.

Taking a call (your telephone rings)

 Lift the handset.
The other party is called.

Canceling (all callback requests)

 Lift the handset.

    Enter the code #58.

Caller ID Suppression (for outbound external call; only if requested from carrier)

Activating

 Lift the handset.

    Enter the code *86.

Deactivating

 Lift the handset.

    Enter the code #86.

Assign Station Number (Not for U.S.)



Lift the handset.



Enter the code *41.



Enter the DID number.



Enter the external code and external station number.

Call Ringing Group

Adding a number to the group (call ringing group on)



Lift the handset.



Enter the code *81.



Enter the internal station number of the telephone to be added to the group.

Deactivating (call ringing group off)



Lift the handset.



Enter the code #81.

Hunt Group/Group Call

Joining hunt group



Lift the handset.



Enter the code *85.

Leaving hunt group



Lift the handset.



Enter the code #85.

Actuating Relays

Activating permanently or momentarily
(check with System Support)



Lift the handset.



Enter the code *90.



Enter the required relay number (0 - 4).

Deactivating



Lift the handset.



Enter the code #90.



Enter the required relay number (0 - 4).

Trunk Flash, Recall to Network

You have set up an external call via an analog line



Press the key.



Enter the code *51.



Enter the service code and/or station number.

Station COS Changeover (Locking/Unlocking Telephone)

Changeover on (locking - first define PIN)



Lift the handset.



Enter the code *66.



Enter your PIN.

Changeover off (unlocking)



Lift the handset.
You hear a special dial tone.



Enter the code # 66.



Enter your PIN.

Defining your PIN:

(If you have forgotten your PIN, System Support can help you. Simply dial 11.)



Lift the handset.



Enter the code *93.



Enter your old PIN (default 00000)



Enter your new PIN twice.

Telephone Data Service

You have established an external connection:



Press the key.



Enter the code *42.



Dial 0 - 9 or #0 - #9 and other suffix as necessary.

Appointment Reminder

Entering an appointment



Lift the handset.



Enter the code *46.



Enter the time as a four-digit number, such as 0905 for 9.05 h. (= 9:05 a.m.) or 1430 for 14.30 h. (= 2:30 p.m.).

Deleting an appointment



Lift the handset.



Enter the code #46.

Acknowledging an appointment call



Lift the handset and replace it again.

Activate Door Opener function

Door release on



Lift the handset.



Enter the code *89.



Enter the internal station number of the entrance telephone.



Enter five-digit code (default = 00000; consult System Support) and the type of door release (1=release with call, 2=release without call).

Door release off



Lift the handset.



Enter the code #89.



Enter the internal station number of the entrance telephone.

Open Door

You are speaking to someone on the door phone



Press the key.



Enter the code *61.



Enter the internal station number of the entrance telephone.

Call Pickup - Directed

Picking up a specific call (another telephone rings)



Lift the handset.



Enter the code *59.



Dial the number of the ringing telephone.

Call Pickup - Group

A telephone in your call pickup group rings



Lift the handset.



Enter the code *57.

Call Forwarding

Forwarding internal/external calls



Lift the handset.
(If call forwarding is already activated,
you hear a special dial tone.)



Enter the code *11.



Internal destination:

Enter the internal number.

External destination:

Possible if the system configuration allows.
Enter the external code and external station
number, then wait for a brief bleep tone.

Forwarding external calls



Lift the handset.
(If call forwarding is already activated,
you hear a special dial tone.)



Enter the code *12.



Internal destination:

Enter the internal number.

External destination:

Possible if the system configuration allows.
Enter the external code and external station
number, then wait for a brief bleep tone.

Forwarding internal calls



Lift the handset.
(If call forwarding is already activated,
you hear a special dial tone.)



Enter the code *13.



Internal destination:

Enter the internal number.

External destination:

Possible if the system configuration allows.
Enter the external code and external station
number, then wait for a brief bleep tone.

Deactivating call forwarding

Lift the handset.
(If call forwarding is already activated,
you hear a special dial tone.)



Enter the code # 1.

MSN Trunk Forwarding (Only in a Multi-Device Connection with Release 2.2 or Later, Not for the U.S.)

Activating

Lift the handset.
If call forwarding has already been activated,
a special dial tone sounds.



Enter the code *64.



Enter the forwarding method (1=immediate,
2=on no answer, 3=on busy),

Enter your own MSN.

Enter the destination number without the ex-
ternal code.

Deactivating

Lift the handset.
When call forwarding is deactivated,
a special dial tone sounds.



Enter the code #64.



Enter the forwarding method (1=immediate,
2=on no answer, 3=on busy),

Enter your own MSN.

Retrieve Line

Call is on hold and has been parked on a line



Lift the handset.



Enter the code *63.



Enter the line number.

Central COS Change

Locking/Unlocking another telephone



Lift the handset.



Enter the code *943.



Enter the station number.



Enter the * = **Locking**

or



Enter the # = **Unlocking**

Meaning of Functions

A brief description of all possible functions is provided below. The functions you can use depend on the individual class of service of your telephone and on the configuration of your system.

Accepting a waiting call (call waiting) (→ 9)

While a call is in progress you can answer a second call that is waiting.

Account code (→ 24)

You can assign the call data of external connections to specific projects (codes).

Appointments (→ 30)

You can enter a single appointment that will take place in the next twenty-four hours.

Assign station number (not for U.S.) (→ 26)

Before you dial an external number, you can assign a different telephone number to your own line and have this number appear on the called party's display.

Associated dialing (→ 14)

You can set up connections for other telephones.

Associated service (→ 13)

You can activate and deactivate functions for other telephones.

Call forwarding (diversion) (→ 33)

Your calls can be forwarded to another telephone including external destinations.

Call pickup - directed (→ 32)

You can answer calls for another telephone from your own telephone.

Call pickup - group (→ 32)

You can pick up calls for telephones within a call pickup group from your telephone.

Call ringing group - on (→ 26)

You can signal calls on other telephones and answer them there, for example if you are away from your station or your line is busy.

Call transfer/Start transfer (call transfer) (→ 7)

If the person you are speaking to wants to talk to another party, you can dial the other party and transfer the call.

Release 2.2 and later: you can announce and transfer a call to a group of users with a speaker call.

Call waiting (→ 9)

You can let a busy internal party know that you want to talk.

Callback (→ 25)

You can request that a party whose number you have dialed should automatically call back.

Caller ID suppression, external (→ 25)

Before dialing an external number you can suppress the display of the caller's telephone number and name on the called party's screen.

Central COS change (→ 35)

You can lock other telephones to prevent unauthorized use, and unlock them again.

Conference, five-party (→ 18)

You can add additional parties to a call.

Consultation hold (→ 7)

You can call a second party while engaged in a call.

DISA (Direct Inward System Access)

From an external location you can activate and deactivate functions in your system in the same way as an internal party. From an external location you can also set up outgoing external calls via your system.

Do not disturb (→ 10)

You can temporarily suppress calls (silent ringing).

Door opener function - activate(→ 31)

You can allow a visitor to activate the door opener by entering a code.

DTMF dialing (dual-tone multifrequency dialing, also called tone dialing),**DTMF suffix dialing (→ 20)**

You can transmit DTMF signals during a call, for example, to access an answering machine.

Hotline (automatic connection setup)

Your telephone can be configured so that a connection to a definable destination is made either immediately or after a certain time (time-dependent hotline) after you lift the handset.

Hunt (group/group call) (→ 27)

If you belong to a group of users who can be reached under a common telephone number in the hunt group/group call, you can leave the group and then join it again. Calls to the hunt group/group call are not signaled at a station which has left the group.

Hunt group = the telephones ring one after the other.

Group call = the telephones ring simultaneously.

Log on CMI unit (not for U.S., → 21)

In order to log on with a CMI unit (cordless telephone) you must place your system in readiness to log on.

MSN trunk forwarding

(Only in multi-device connections with Release 2.2 and later, not for the U.S → 34.)

You can forward your assigned MSN (DID number) directly to an external destination in the public network.

Night answer (→ 22)

You can forward all calls to a fixed destination (default destination) or to a destination that you define yourself, such as after business hours.

Open door (→ 31)

You can activate the door opener from your telephone.

Override (→ 14)

You can override a colleague's busy connection to speak to your colleague. A dual-tone signal sounds in your colleague's phone.

Park call (→ 23)

You can place voice calls on hold and pick them up again from another telephone.

Preventing/allowing call waiting (→ 10)

You can prevent or allow a second call to be signaled by automatic call waiting while a call is in progress.

Radio paging (not for U.S., → 24)

If paging equipment is connected to your system, you can contact people via their assigned pocket receivers. The person you page can then go to the nearest telephone and call you.

Relay (→ 28)

You can activate and deactivate particular devices (such as relays).

Release trunk (→ 20)

You can release busy external trunks. Active calls on that trunk are disconnected. The trunk is free again and can be used for external calls once more.

Reserve trunk (→ 6)

You can reserve a busy external trunk for yourself automatically.

Reset services (→ 15)

You can reset activated functions.

Retrieve line (→ 35)

After an external call has been placed on hold, you can pick it up or retrieve it on the assigned line.

Room monitor (baby phone) (→ 15)

You can acoustically monitor a specific room.

Sending and retrieving a message text (→ 17/→ 16)

You can send predefined messages to colleagues who have optiset E system telephones. Although your telephone signals the messages sent to you, they are not displayed. Retrieving a message automatically sets up a connection to the sender.

Silent monitor (U.S. only, → 21)

If you have the appropriate authorization, you can switch into an internal party's ongoing call and listen unnoticed to the call.

Speaker call (→ 16)

You can talk to another party via the loudspeaker on the other party's telephone.

Speed dial - station (→ 19)

You can save and dial up to ten individual destination numbers under the numeric keys *0 through *9.

Speed dial - system (→ 19)

By entering three-digit speed dial numbers you can dial destination numbers stored in a central location.

Station COS changeover (locking telephone, → 29)

You can prevent unauthorized use during your absence. You can define your own PIN (lock code) needed for this purpose.

Telephone data service (→ 30)

You can use your telephone to control computers connected to your system or programs running on them, such as hotel services or information systems.

Toggle (→ 20)

You can alternate between two existing calls.

Trace call (only if requested from the carrier, not for U.S., → 16)

You can have the carrier identify malicious external callers.

Trunk flash (→ 28)

If you want to use features such as consultation hold over analog lines, you must send a signal to the line before dialing the number.

UCD (uniform call distribution) (→ 11)

You can be distribute calls in a team. An incoming call is always assigned to the team member (agent) who has had the longest break without a call.

You must **log on** and **log off** with the system at the beginning and end of work.

During working hours you can indicate to the system that you are **available/not available**, for example for break periods.

If you need time to complete paperwork resulting from your current call before **activate/deactivate** a period of **work time** for the last call.


You can **activate/deactivate** a separate **night answer** service for UCD; this is not subordinate to the system night answer service.



Overview of Codes

Functions	DTMF tele-phones	Pulse tele-phones
Accept waiting call (call waiting)	*55	75 55
Call waiting on	#490	76 490
Call waiting off	*490	75 490
Account code	*60	75 60
Appointment - entering	*46	75 46
Appointment - deleting	#46	76 45
Assign station number (not for U.S.)	*41	75 41
Associated dialing	*67	75 67
Associated service	*83	75 83
Call forwarding on		
All calls	*11	75 11
Only external calls	*12	75 12
Only internal calls	*13	75 13
Call forwarding off	#1	76 1
Call pickup - directed	*59	75 59
Call pickup - group	*57	75 57
Call ringing group on	*81	75 81
Call ringing group off	#81	76 81
Callback - initiating	*58	75 58
Callback - canceling	#58	76 58
Caller ID suppression on	*86	75 86
Caller ID suppression off	#86	76 86
Central COS change	*493	75 493
Changeover on (lock telephone)	*66	75 66
Changeover off (unlock telephone)	#66	76 66
Define PIN (locking code)	*93	75 93
Conference, initiating	*3	75 3
Conference, ending	#3	76 3
Remove ISDN central office party from the conference (only for U.S.)	*491	75 491
Consultation hold - ending	*0	75 0
Do not disturb on	*97	75 97
Do not disturb off	#97	76 97
Door release on	*89	75 89
Door release off	#89	76 89
DTMF (tone dialing)	---	75 53
Hunt group/group call		
Joining	*85	75 85
Leaving	#85	76 85
Log on CMI unit (not for U.S.)	*942	75 942

Functions	DTMF tele- phones	Pulse tele- phones
MSN trunk forwarding (only in multi-device connections with Release 2.2 and later, not for the U.S.)		
On	* 64	75 64
Off	# 64	76 64
Night answer on	* 44	75 44
Night answer off	#44	76 44
Open door	* 61	75 61
Override	* 62	75 62
Paging another person	* 45	75 45
Answering	#45	76 45
(not for U.S.)		
Park call	* 56	75 56
Retrieve parked call	#56	76 56
Relay on	* 90	75 90
Relay off	#90	76 90
Release trunk	* 43	75 43
Reset all services	#0	76 0
Retrieve line	* 63	75 63
Room monitor, baby phone	* 88	75 88
Send message text	* 68	75 68
Delete message text (after sending)	#681	76 681
Retrieve message texts	* 683	75 683
Silent monitor (U.S. only)	* 944	75 944
Speaker call	* 80	75 80
Speed dial: dialing	* 7	75 7
Speed dial - station: storing	* 92	75 92
Telephone data service	* 42	75 42
Toggle	* 2	75 2
Trace call (not for U.S.)	* 84	75 84
Trunk flash (recall to network)	* 51	75 51
UCD (automatic call distribution)		
Log on (start of duty)	* 401	75 401
Log off (end of duty)	#401	76 401
Log back on after temporary logoff	* 402	75 402
Log off temporarily	#402	76 402
Request work time	* 403	75 403
Log back on after work time	#403	76 403
UCD night answer on	* 404	75 404
UCD night answer off	#404	76 404



All analog telephones connected to the Siemens Hicom 150 E Office systems shall be hearing aid compatible and comply with the applicable FCC Rules, Part 68 and Industry Canada CS-03 Standard.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to the equipment that are not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment.

This equipment does not exceed Class B limits per radio noise emissions for digital apparatus, set out in the Radio Interference Regulation of the Canadian Department of Communications. Operation in a residential area may cause unacceptable interference to radio and TV reception requiring the owner or operator to take whatever steps are necessary to correct the interference.

Cet équipement ne dépasse pas les limites de Classe B d'émission de bruits radioélectriques par les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique établi par le ministère des Communications du Canada. L'exploitation faite en milieu résidentiel peut entraîner le brouillage des réceptions radio et télé, ce qui obligerait le propriétaire ou l'opérateur à prendre les dispositions nécessaires pour en éliminer les causes.

May 2000

Job No. 5003

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, mechanical, electronic, photocopying, recording, or otherwise, without prior written permission of Siemens Information and Communication Networks, Inc.

Request Siemens publications from your Siemens representative or the Siemens branch serving you. Publications are not stocked at the address below.

Siemens Information and Communication Networks, Inc.

4900 Old Ironsides Drive

P.O. Box 58075

Santa Clara, CA 95052-8075

(408) 492-2000

Siemens, optiset, Hicom, and PhoneMail are registered trademarks of Siemens Aktiengesellschaft.

Copyright Siemens Information and Communication Networks, Inc. 2000.
All rights reserved.

Speed Dial Destinations

You can enter your individual or system speed dial destinations here.
Please consult System Support for the system speed dial destinations.

Speed dial number	Company/name

Siemens Information and Communication Networks, Inc.
4900 Old Ironsides Drive
P.O. Box 58075
Santa Clara, CA 95052-8075

Siemens reserves the right to change
specifications without notice.

© Copyright Siemens Information and Communication Networks, Inc.
2000. All rights reserved.

Printed in the U.S.A.

